

How can I lock the touch function on IFP5550/IFP6550/ IFP7550/IFP8650?

Modified on: Sun, 24 Jan, 2021 at 9:30 PM

Applied model:

1. Americas: IFP**50 - Gen 1, IFP**50 - Gen 2, IFP**50 - Gen 3.
2. Asia Pacific & Africa: IFP**50, IFP**50-2, IFP**50-3.
3. Europe: IFP**50, IFP**50-2EP, IFP**50-3EP.

Please refer either method below:

- 1.You will need to set combination key to “ON” at Debug menu→Other Setting→ Combination key.

Then the touch function can be locked/unlocked by pressing the following front panel buttons in sequence:

VOL+, VOL+, VOL+, SETTING, HOME

- 2.You can enter Debug menu→Other Setting then set touch lock to be ON.